

# S-WORKS TURBO RAPIDAIR INSTALLATION

## 手順はたったの4つ

RapidAir タイヤは、スペシャライズド史上最速のタイヤであるだけでなく、取付がとても簡単なチューブレスタイヤです。タイヤを交換できる方なら誰でもコンプレッサーなしで完了できるほど簡単ですが、以下の4つの手順に従い、確実に取り付けましょう。

### 1 お使いのチューブレスレディーホイールを確認しましょう。

リムテープがシワにならず、また損傷していない状態でリムに正しく取り付けられていることを確認します。異常がある場合は、新しいリムテープに交換してください。バルブシステムが正しく装着され、適切に締め付けられ、Oリングが損傷していないことを確認します。

### 3 もう片方のビードも取り付けましょう。

最初にはめたビードがリムの溝の中心にあるのを確認した上で、バルブの反対側からもう片方のビードを押し上げ、同様に溝の中心に落とします。

RapidAir シーラントの注入方法は2種類。ボトルの内容物を均一に出せるよう、注入直前に必ずボトルをよく振ってください。

方法その1：最後のビードをはめ終える前に、数センチ分をはめないで隙間を作っておき、そこから推奨量（タイヤ1本につき60mlが適量）のシーラントを入れ、ホイールを180度回転させてから、残りのビードをはめます。

方法その2：両側のビードを完全にはめ終えたあと、バルブコアを外してバルブシステムにシーラントを注入してから、バルブコアを元に戻し、バルブシステムを適切な力で締め付けます。

### 2 片方のビードを取り付けましょう。

片方のビードを、リム上のバルブと反対側の位置にセットします。両手の親指でビードをリムに押し上げます。タイヤを取り付ける際は、ビードがリムウォールと接しているのではなく、溝の中心に落ちていることを確認してください。こうすることでビードが緩み、リムウォールの内側へ押し込みやすくなります。

### 4 タイヤに空気を入れましょう。

フロアポンプでタイヤを最大圧力（700x26cであれば100 PSIまたは7.0 bar、700x28cであれば95 PSIまたは6.5 bar）まで充填します。5分ほど走行し、シーラントをタイヤ全体に行き渡らせてから、お好みの走行空気圧にセットしてください。この空気圧は、チューブ使用時より10~15 PSI低くなる場合が多いです\*。

\*一回の充填量の少ないフロアポンプをお使いの場合、バルブコアを外してより多くの空気を送り込むことで、ビードを上げられます。石鹸水でビードを濡らすと、より簡単に空気を入れられます。

# COMPATIBILITY CHART S-WORKS TURBO RAPIDAIR

## INSTALLATION CHECK S-WORKS TURBO RAPIDAIR, 00019-1152, 00019-1153

				MOUNTING W/O TIRE LEVER		INFLATION WITH FLOORPUMP	
				26c	28c	26c	28c
Bontrager	Aeolus Pro 3 TLR Disc	Carbon	19-622	ok	ok	ok	ok
Campagnolo	Bora WTO 2-Way-Fit	Carbon	19-622	ok	ok	ok	ok
Campagnolo	Shamal Ultra 2-Way-Fit	Alloy	19-622	ok	ok	ok	ok
Campagnolo	Scirocco Disc Brake 2-Way-Fit	Alloy	19-622	ok	ok	ok	ok
DT Swiss	E 1800 Spline	Alloy	20-622	ok	ok	ok	ok
DT Swiss	ARC 1400 Dicut	Carbon	17-622	ok	ok	ok	ok
DT Swiss	ARC 1100 Dicut	Carbon	17-622	ok	ok	ok	ok
DT Swiss	PRC 1100 Dicut	Carbon	18-622	ok	ok	ok	ok
DT Swiss	PRC 1400 Spline	Carbon	18-622	ok	ok	ok	ok
DT Swiss	PR 1400 Dicut Oxic	Alloy	18-622	ok	ok	ok	ok
DT Swiss	PR 1400 Dicut	Alloy	18-622	ok	ok	ok	ok
DT Swiss	PR 1600	Alloy	18-622	ok	ok	ok	ok
DT Swiss	P 1800	Alloy	18-622	ok	ok	ok	ok
DT Swiss	ERC 1100 Dicut	Carbon	19-622	ok	ok	ok	ok
DT Swiss	ERC 1400 Spline	Carbon	19-622	ok	ok	ok	ok
DT Swiss	ER 1400	Alloy	20-622	ok	ok	ok	ok
DT Swiss	ER 1600	Alloy	20-622	ok	ok	ok	ok
DT Swiss	R470 Rim	Alloy	20-622	with lever	with lever	ok	ok
Easton	EC 90 Aero 55 Clincher Tubeless	Carbon	19-622	ok	ok	ok	ok
Easton	EC 90 SL 38	Carbon	19-622	ok	ok	ok	ok
Enve	SES 4.5 hookless	Carbon	25-622	with lever	with lever	ok	ok
Enve	SES 2.2	Carbon	19-622	ok	ok	ok	ok
Enve	SES 3.4 Disc	Carbon	21-622	ok	ok	ok	ok
Enve	SES 5.6	Carbon	20-622	ok	ok	ok	ok
Enve	SES 7.8 Disc	Carbon	21-622	ok	ok	ok	ok
Fulcrum	Racing Zero DB	Alloy	19-622	ok	ok	ok	ok
Fulcrum	Racing Zero DB	Carbon	19-622	ok	ok	ok	ok
Fulcrum	Racing Zero Competizione	Alloy	17-622	ok	ok	ok	ok
Fulcrum	Racing 3 DB	Alloy	19-622	ok	ok	ok	ok
Mavic	Comete Pro Carbon SL UST DB	Carbon	19-622	with lever	with lever	ok	ok
Mavic	Comete Pro Carbon SL UST	Carbon	19-622	with lever	with lever	ok	ok
Mavic	Cosmic Pro Carbon SL UST DB	Carbon	19-622	with lever	with lever	ok	ok
Mavic	Cosmic Pro Carbon SL UST	Carbon	19-622	with lever	with lever	ok	ok
Mavic	Cosmic Pro Carbon UST DB	Carbon	19-622	with lever	with lever	ok	ok
Mavic	Cosmic Pro Carbon UST	Carbon	19-622	with lever	with lever	ok	ok
Mavic	Cosmic Elite UST DB	Alloy	17-622	with lever	with lever	ok	ok
Mavic	Cosmic Elite UST	Alloy	17-622	with lever	with lever	ok	ok
Mavic	Ksyrium PRO Carbon SL UST DB	Carbon	21-622	ok	ok	ok	ok
Mavic	Ksyrium PRO Carbon SL UST	Carbon	19-622	ok	ok	ok	ok
Mavic	Ksyrium PRO Carbon UST DB	Carbon	21-622	ok	ok	ok	ok
Mavic	Ksyrium PRO UST DB	Alloy	19-622	ok	ok	ok	ok
Mavic	Ksyrium PRO UST	Alloy	17-622	with lever	with lever	ok	ok
Mavic	Ksyrium Elite UST DB	Alloy	19-622	ok	ok	ok	ok
Mavic	Ksyrium Elite UST	Alloy	17-622	with lever	with lever	ok	ok
Mavic	Ksyrium UST DB	Alloy	19-622	ok	ok	ok	ok
Mavic	Ksyrium UST	Alloy	17-622	with lever	with lever	ok	ok
Mavic	Aksium Elite UST DB	Alloy	19-622	ok	ok	ok	ok
Mavic	Aksium Elite UST	Alloy	19-622	ok	ok	ok	ok
Roval	Rapide CLX (32.50.64)	Carbon	21-622	ok	ok	ok	ok
Roval	Rapide CL (32.50.64)	Carbon	21-622	ok	ok	ok	ok
Roval	SLX 24	Alloy	20-622	ok	ok	ok	ok
Shimano	Dura Ace 9100 Tubeless	Carbon	17-622	ok	ok	ok	ok
Stans	Grail CB7	Carbon	21,6-622	ok	ok	ok	ok
Zipp	30 Course	Alloy	21-622	ok	ok	ok	ok
Zipp	202 Firecrest Tubeless DB	Carbon	21-622	ok	ok	ok	ok
Zipp	303 Firecrest Tubeless DB	Carbon	21-622	ok	ok	ok	ok
Zipp	202 NSW Tubeless DB	Carbon	21-622	ok	ok	ok	ok
Zipp	303 NSW Tubeless DB	Carbon	21-622	ok	ok	ok	ok